

User Manual — NETSTAT Slim Mouse, Pink

Pink slim wireless mouse, ideal for office.

CONTENTS

1. General Presentation
2. What's in the Box
3. Wireless 2.4G Connection
4. Specifications
5. Power
6. Troubleshooting
7. Usage & Care Tips
8. Certificate of Warranty

1 General Presentation

Congratulations on choosing NETSTAT Slim Mouse, Pink! You picked a reliable mouse with precise tracking and a stable connection. This manual helps you set it up and use it correctly. We are here for you non-stop — if you have any question, message us on WhatsApp and we are happy to help.

2 What's in the Box

- 1 x Mouse
- 1 x USB Receiver
- 1 x Manual

3 Wireless 2.4G Connection

1. Take the nano USB receiver out of the package (or the product compartment).
2. Plug the receiver into a free USB port on your computer.
3. Turn the product on with the ON/OFF switch (if present) — it connects automatically within seconds.
4. Keep the USB receiver in a safe place or in the product compartment (if available).

The 2.4G connection has a range of up to 10 m and low latency. If the signal is weak, use a USB extension to bring the receiver closer.

4 Specifications

- Slim design
- Wireless 2.4GHz
- Compatibility: Windows, macOS, Linux

5 Power

- The mouse has an ON/OFF switch on the underside — turn it on before use.
- It is battery powered. If the mouse does not respond, check or replace the battery.
- To save power, switch the mouse off when not in use.
- The USB receiver can be stored in the mouse compartment for travel (if available).

6 Troubleshooting

Mouse not responding	Check the ON/OFF switch, replug the USB receiver in another port, and check/charge the battery.
Jerky or imprecise cursor	Use on a smooth surface or mousepad; clean the optical sensor lens.
Button or scroll not working	Clean dust around the buttons and wheel; test on another computer.
Intermittent connection	Bring the receiver closer (use a USB extension) and avoid interference (USB 3.0 hubs, metal objects).

7 Usage & Care Tips

- Clean periodically with a soft, slightly damp cloth — do not use solvents or abrasives.
- Keep the product away from moisture, excessive dust and extreme temperatures (direct sun, radiators).
- Do not drop the product or carry it by the cable — plug/unplug by holding the connector.
- Keep the box and warranty card — they are useful for returns or warranty service.
- Use it on a matte, even surface or a mousepad — not on glass or a mirror.
- Clean the optical sensor lens underneath if tracking becomes imprecise.

8 Certificate of Warranty

- Warranty period: 2 years from the purchase date for hardware defects.
- Within 7 days: replacement if appearance and packaging are complete (with valid proof of purchase).
- Within 60 days: replacement at the point of purchase or the designated service centre.
- Within 2 years: repair or replacement at the designated service centre — delivered to your address.
- Contact: NETSTAT TRADING SRL, Bucharest, Sector 4 · +40 736 374 440.